



ASSEMBLY INSTRUCTIONS – BOX FRAMES

Your kit will come as flat pack pieces. You can paint, decorate, or line the parts before assembly but avoid getting anything in the joints or assembly will be difficult. Doing a “dry run” first (no glue!) can help with knowing what should go where!

Always use a good quality wood glue and brush onto both pieces to be glued together. You may find low tack masking tape useful to hold things together while drying. Make sure you wipe away any glue oozes immediately with a damp cloth.



Assemble the 4 box frame sides making sure the slots are all same side up. Attach the back of the frame and if required, glue on the wall hook using the engraved outline as a placement guide.



Glue the 2 frame pieces together which creates the recess for the perspex window to drop in.

Use the dowel supplied and cut to your preferred length to create the pegs – score round the dowel with a sharp craft knife and it will cut or snap easily. Any left over can be used for other projects (makes good mini sign posts or plant pot picks!).

Tap the pegs into the pre-drilled holes and slot on the frame catches/turns – no glue required. It should be quite a tight fit to hold the frame securely, but with enough give to rotate them should you wish to remove the frame in the future.



Once all the glue has dried, sit the frame onto the front of the box and turn the catches into the slots on the box to secure the box frame together.



Once assembled, you can hang the box frames on a wall, prop on a shelf, bookcase or mantelpiece. As the frame is removable, you can change the contents of the box as often as you like.

We hope you have enjoyed putting your kit together!