

## <u>Assembly Instructions – Tudor Framed House Kit</u>

When you receive your kit it will come with all the individual pieces ready to assemble. Use a good quality glue for best results.  You can paint the parts before assembly but ensure you avoid the finger joins or assembly may be difficult. If you are going to cover any parts with paper, use the unassembled parts as a pattern.
Assemble the 4 walls, ensure any engraved details are on the outside.
Attach the roof parts.  You may wish to use low tack masking tape or elastic bands to hold the piece together as it dries.
Glue on the exterior frame pieces and attach the porch roof.
And that's it – we hope you've enjoyed putting your kit together.