








Assembly Instructions – Medieval Church Kit

 A 3D perspective rendering of the assembled medieval church kit. The model is made of light brown cardboard and features a main rectangular body with arched windows, a smaller square tower with a crenellated top and a cross, and a pointed-arch doorway.	<p>When you receive your kit it will come with all the individual pieces ready to assemble. Use a good quality glue for best results.</p> <p>You can paint the parts before assembly but ensure you avoid the finger joins or assembly may be difficult. If you are going to cover any parts with paper, use the unassembled parts as a pattern.</p>
 An isometric diagram showing the four individual wall pieces of the church. Red lines indicate the intended assembly points and orientation for each wall.	<p>Assemble the 4 walls, ensure good sides and any engraved details are facing out.</p> <p>Please note: This kit does not have a hinged door.</p>
 An isometric diagram showing the interior arches and columns being inserted into the previously assembled walls. Red lines indicate the placement of these internal structural elements.	<p>Insert the interior arches/columns.</p> <p>You may wish to use low tack masking tape to hold the piece together as the glue dries.</p>
 An isometric diagram showing the three chancel walls being attached to the main church building. Red lines indicate the attachment points for these additional wall sections.	<p>Assemble the 3 Chancel walls and attach to the main Church building.</p> <p>Attach the Chancel roof pieces.</p>



Attach the roof pieces to the nave and aisles on the main Church building.



Assemble the Church tower and attach this to the front of the Church building.

Glue the cross on top of the tower and add the window frames – that's it! We hope you've enjoyed putting your kit together and have fun decorating it.